

LG ELECTRONICS INC.

TEST REPORT

SCOPE OF WORKS

EVALUATION OF STERILIZATION EFFICIENCY OF ANTIBACTERIAL (스팀통살균) CYCLE IN DRYER

REPORT NUMBER

RT21E-S0054

ISSUE DATE

17-SEP-2021


PAGES

18

DOCUMENT CONTROL NUMBER

ISTC-QP-FM-17-03-E1 Rev.1

© 2017 INTERTEK



TEST REPORT FOR LG ELECTRONICS INC.

Report No.: RT21E-S0054

Date: SEP. 17, 2021

OBJECTIVE

The purpose of the testing is:

To evaluate the antibacterial efficacy of 스팀통살균 cycle from the components of the dryer.

HYPOTHESIS

스팀통살균 cycle will remove more than 99.9 % of the bacteria in the components of the dryer.

CONCLUSION

Based on the data collected, the Hypothesis is accepted:

스팀통살균 cycle can remove more than 99.9 % of the bacteria in the components of the dryer.

Rody Ju

ENGINEER



Bo Park

Laboratory Director



CONDUCTED AT	LG ELECTRONICS INC.
WITNESSED AT	INTERTEK TESTING SERVICES KOREA LTD.
PERIOD OF TEST	13 SEP 2021 ~ 17 SEP 2021
DATE OF ISSUE	17 SEP 2021

Except where explicitly agreed in writing, all work and services performed by Intertek is subject to our standard Terms and Conditions which can be obtained at our website: <http://www.intertek.com/terms/>. Intertek's responsibility and liability are limited to the terms and conditions of the agreement. This report is made solely on the basis of your instructions and / or information and materials supplied by you and provide no warranty on the tested sample(s) be truly representative of the sample source. The report is not intended to be a recommendation for any particular course of action, you are responsible for acting as you see fit on the basis of the report results. Intertek is under no obligation to refer to or report upon any facts or circumstances which are outside the specific instructions received and accepts no responsibility to any parties whatsoever, following the issue of the report, for any matters arising outside the agreed scope of the works. This report does not discharge or release you from your legal obligations and duties to any other person. You are the only one authorized to permit copying or distribution of this report (and then only in its entirety). Any such third parties to whom this report may be circulated rely on the content of the report solely at their own risk. This report shall not be reproduced, except in full.

Date: AUG. 10, 2021

SECTION 1**INDEX**

SECTION NAMES	PAGE
Objective	4
Parameters	4
Product/Model Description	5
Sample acquisition	5
Hypothesis	5
Technical staff	6
Test procedure	7-8
Test result	9-12
Conclusion	13
Appendix I. Photos of model	14
Appendix II. Photos of result	15-18

Date: AUG. 10, 2021

SECTION 2

OBJECTIVE

The purpose of the testing is:

To evaluate the antibacterial efficacy of 스팀통살균 cycle from the components of the dryer.

SECTION 3

PARAMETERS

The following parameters are controlled

VALUE	DESCRIPTION	UNITS	METHOD
25 ± 3	Test room temperature	°C	Data logger
40 ± 10	Test room humidity	% R.H.	Data logger
35-37	Incubated Temperature	°C	Data logger

The following parameters are monitored

VALUE	DESCRIPTION	UNITS	METHOD
25 ± 3	Test room temperature	°C	Data logger
40 ± 10	Test room humidity	% R.H.	Data logger
35-37	Incubated Temperature	°C	Data logger

Date: AUG. 10, 2021

SECTION 4**PRODUCT/MODEL DESCRIPTION**

PRODUCT INFORMATION: LG Dryer

MODEL: RD20****, W20****

Note:

SECTION 5**SAMPLE ACQUISITION**

Samples prepared by LG Electronics Co., Ltd.:

SAMPLE #	DESCRIPTION	SERIAL No.	PURCHASE LOCATION	DATE	CONDITION
1	LG Dryer	106KWEL98724	Prepared by LG	2021.07	Packaged and undamaged

SECTION 6**HYPOTHESIS**

스팀통살균 cycle will remove more than 99.9 % of the bacteria in the components of the dryer.

Date: AUG. 10, 2021

SECTION 7**TECHNICAL STAFF**

#	Staff Name	Area of Expertise
1	Younsung Joo	Chemical test engineer / LG Electronics
2	Rody Ju	Technical Manager / Intertek Testing Korea Ltd.
3	Bo Park	Laboratory Director / Intertek Testing Korea Ltd.
Note: Complete training records for staff are available upon request		

Testing was conducted at:

LG Electronics Gasan R&D Campus

51, Gasan digital 1-ro, Geumcheon-gu, Seoul, Republic of Korea

LG Electronics Co., Ltd.

Witnessed by:

Intertek Testing Services Korea Ltd.

4/F, A-JU Digital Tower, 7, Ahasan-ro 5 -gil, Seongdong-gu, Seoul, Korea

Date: AUG. 10, 2021

SECTION 8**TEST PROCEDURE****1. Test Set up :**

Items		Requirement	Condition
Electrical Supply	Voltage	(220 ± 10)	(220 ± 10)
	Frequency	(60 ± 10) Hz	(60 ± 10) Hz
Ambient Temperature		(25 ± 3) °C	(25 ± 3) °C
Ambient humidity		(40 ± 10) % R.H.	(40 ± 10) % R.H.

2. Test materials

2.1 The following bacteria shall be used in the testing:

Staphylococcus aureus ATCC 6538

Escherichia coli ATCC 8739

Pseudomonas aeruginosa ATCC 27853

Klebsiella pneumoniae ATCC 4352

3. Test method

3.1 The test organism shall be resuspended in 50 ml of Tryptic Soy broth and incubated for 24 hr at 35 °C.

3.2 The test organism is serially diluted to the target concentration $10^6 \sim 10^8$ CFU/ml using the PBS (Phosphate Buffered saline).

3.3 200 µl of diluted organism is inoculated into the carriers.

- Carrier size: 5 X 5 cm

3.4 Two of each test carriers from **3.3** will be used as controls.













3.5 Attach the carriers

- test carriers are attached to filter, eva (front), condenser (front), drum-air hole(back), inside the drum, drum lifter, Heat moving path(entrance), Heat moving path (exit), Interior Door, Filter (Bottom), Eva (Bottom)

- The fan attached bacteria using a cotton swab.

Date: AUG. 10, 2021

position of attach

Filter	Eva (Front)	Condenser (Front)	Drum-air Hole (back)	Inside the drum	Drum lifter
					
Heat moving path (entrance)	Heat moving path (exit)	Interior Door	Filter (Bottom)	Eva (Bottom)	Fan
					

3.6 Start 스팀통살균 cycle with electrical supply 220 V, 60 Hz.

3.7 After the 스팀통살균 cycle ends, each carrier will be aseptically removed and put into the 10 ml of PBS and vortex 1 minute.

3.8 Ten-fold serial dilution will be prepared from the eluting solution and plated onto an appropriate recovery agar (or 3M Petri film).

Strain	recovery agar
Staphylococcus aureus	Staph Express Count Plate (3M Petrifilm)
Escherichia coli	E. coli/Coliform Count Plate (3M Petrifilm)
Pseudomonas aeruginosa	Cetrimide Agar Base (Pseudomonas Isolation Agar)
Klebsiella pneumoniae	Sorbitol MacConkey Agar

3.9 All plates incubated for 24 ~ 48 hr at 35 °C.

3.10 Three repeat test be completed.

3.11 Evaluated the data as below Calculation.

$$\text{Percent reduction} = [(a-b)/a] \times 100$$

Where: *a* = geometric mean of the number of organisms surviving on the untreated control carriers (cfu/ml)

b = geometric mean of the number of organisms surviving on the test carriers (cfu/ml)

* According to the 3M petrifilm guide, the preferable counting range on a Petrifilm Aerobic count plate is 10-300 colonies.

Date: AUG. 10, 2021

SECTION 9**TEST RESULT**< *Staphylococcus aureus* >

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	2.7×10^7	-	2.4×10^7	-	3.5×10^7	-
Filter	1.0×10^2	>99.99	0	>99.99	0	>99.99
Eva (Front)	1.1×10^4	99.9	0	>99.99	0	>99.99
Condenser (Front)	8.0×10^2	99.99	1.2×10^4	99.9	1.2×10^3	99.99
Drum-air Hole (back)	7.0×10^1	>99.99	0	>99.99	0	>99.99
Inside the drum	7.9×10^2	99.99	1.6×10^4	99.9	0	>99.99
Drum lifter	1.9×10^2	>99.99	1.0×10^1	>99.99	0	>99.99
Heat moving path (entrance)	1.0×10^1	>99.99	0	>99.99	0	>99.99
Heat moving path (exit)	4.2×10^2	99.99	0	>99.99	0	>99.99
Interior Door	1.3×10^2	>99.99	1.0×10^4	99.9	0	>99.99
Filter (Bottom)	3.8×10^3	99.9	0	>99.99	0	>99.99
Eva (Bottom)	0	>99.99	0	>99.99	4.3×10^2	99.99

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	8.0×10^7	-	5.0×10^7	-	3.8×10^7	-
Fan	0	>99.99	0	>99.99	0	>99.99

Date: AUG. 10, 2021

< Escherichia coli >

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	2.6×10^7	-	2.0×10^8	-	2.1×10^8	-
Filter	0	>99.99	0	>99.99	0	>99.99
Eva (Front)	0	>99.99	0	>99.99	0	>99.99
Condenser (Front)	0	>99.99	3.3×10^3	99.99	1.0×10^1	>99.99
Drum-air Hole (back)	0	>99.99	0	>99.99	0	>99.99
Inside the drum	0	>99.99	2.0×10^3	>99.99	0	>99.99
Drum lifter	0	>99.99	0	>99.99	0	>99.99
Heat moving path (entrance)	0	>99.99	0	>99.99	0	>99.99
Heat moving path (exit)	0	>99.99	1.0×10^1	>99.99	0	>99.99
Interior Door	0	>99.99	1.8×10^2	>99.99	0	>99.99
Filter (Bottom)	0	>99.99	0	>99.99	0	>99.99
Eva (Bottom)	1.0×10^1	>99.99	0	>99.99	0	>99.99

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	1.8×10^8	-	6.3×10^8	-	1.2×10^8	-
Fan	0	>99.99	0	>99.99	0	>99.99

Date: AUG. 10, 2021

< Pseudomonas aeruginosa >

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	1.0×10^6	-	4.0×10^5	-	5.0×10^5	-
Filter	0	>99.99	0	>99.99	0	>99.99
Eva (Front)	0	>99.99	0	>99.99	0	>99.99
Condenser (Front)	0	>99.99	0	>99.99	0	>99.99
Drum-air Hole (back)	0	>99.99	0	>99.99	0	>99.99
Inside the drum	0	>99.99	0	>99.99	0	>99.99
Drum lifter	0	>99.99	0	>99.99	0	>99.99
Heat moving path (entrance)	0	>99.99	0	>99.99	0	>99.99
Heat moving path (exit)	0	>99.99	0	>99.99	0	>99.99
Interior Door	0	>99.99	0	>99.99	0	>99.99
Filter (Bottom)	0	>99.99	0	>99.99	0	>99.99
Eva (Bottom)	0	>99.99	0	>99.99	0	>99.99

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	7.7×10^6	-	2.5×10^7	-	1.3×10^7	-
Fan	0	>99.99	0	>99.99	0	>99.99

Date: AUG. 10, 2021

< *Klebsiella pneumoniae* >

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	2.6×10^6	-	3.5×10^7	-	1.2×10^7	-
Filter	0	>99.99	0	>99.99	0	>99.99
Eva (Front)	0	>99.99	0	>99.99	0	>99.99
Condenser (Front)	0	>99.99	3.6×10^3	99.9	0	>99.99
Drum-air Hole (back)	0	>99.99	0	>99.99	0	>99.99
Inside the drum	0	>99.99	1.9×10^3	99.99	0	>99.99
Drum lifter	0	>99.99	0	>99.99	0	>99.99
Heat moving path (entrance)	0	>99.99	0	>99.99	0	>99.99
Heat moving path (exit)	0	>99.99	0	>99.99	0	>99.99
Interior Door	0	>99.99	2.5×10^2	>99.99	0	>99.99
Filter (Bottom)	2.0×10^1	>99.99	0	>99.99	0	>99.99
Eva (Bottom)	0	>99.99	0	>99.99	0	>99.99

Sample name	Test 1 (CFU/ml)	% Reduction	Test 2 (CFU/ml)	% Reduction	Test 3 (CFU/ml)	% Reduction
Control	1.7×10^7	-	8.0×10^7	-	2.0×10^7	-
Fan	0	>99.99	0	>99.99	0	>99.99

Date: AUG. 10, 2021

SECTION 10

CONCLUSION

Based on the data collected the Hypothesis is accepted:

스팀통살균 cycle can remove more than 99.9 % of the bacteria in the components of the dryer.

APPENDIX I. Photos of sample



Date: AUG. 10, 2021

Appendix II. Photos of result**< Staphylococcus aureus >**

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Drum lifter			
Filter				Heat moving path (entrance)			
Eva (Front)				Heat moving path (exit)			
Condenser (Front)				Interior Door			
Drum-air Hole (back)				Filter (Bottom)			
Inside the drum				Eva (Bottom)			

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Fan			

Date: AUG. 10, 2021

< Escherichia coli >

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Drum lifter			
Filter				Heat moving path (entrance)			
Eva (Front)				Heat moving path (exit)			
Condenser (Front)				Interior Door			
Drum-air Hole (back)				Filter (Bottom)			
Inside the drum				Eva (Bottom)			

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Fan			

Date: AUG. 10, 2021

< Pseudomonas aeruginosa >

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Drum lifter			
Filter				Heat moving path (entrance)			
Eva (Front)				Heat moving path (exit)			
Condenser (Front)				Interior Door			
Drum-air Hole (back)				Filter (Bottom)			
Inside the drum				Eva (Bottom)			

Sample name	Test 1	Test 2	Test 3	Sample name	Test 1	Test 2	Test 3
Control				Fan			

Report No.: RT21E-S0054

Report No.: RT21E-S0054

Report No.: RT21E-S0054

Report No.: RT21E-S0054

Report No.: RT21E-S0054